BUSHWAKKA®
ADVENTURE GEAR

HEATED MOON CHAIR

BATTERY PACK NOT INCLUDED

INSTRUCTIONS:

**Purchase a battery pack that is suitable to power the chair
(recommended battery pack power: 10,000 mAh)**

STEP 1:

Plug in battery* and place in the pocket under seat.

STEP 2:

Push power button and hold for 3 seconds.

STEP 3:

Change temperature by pushing button.

LOW	MED	HIGH
38˚C/100˚F	45˚C/113˚F	55˚C/131˚F

Setting	LED Color	Celsius	Fahrenheit	10 000mAh
Low	Green	38˚C	100˚F	6 hrs.**
Med	Yellow	45˚C	113˚F	4 hrs.**
High	Red	55˚C	131˚F	2 hrs.**

STEP 4:

To turn off, push power button and hold for 3 seconds.